


Automatic Door Systems



TH-W2







Telescopic 4-winged Sliding doors

Telescopic 2-winged Sliding doors

<http://www.kthtw.com>
e-mail: kth@kthtw.com


OPERATION INSTRUCTION

The Door-Leaf sends out abnormal noise in operating.

<p>Cause 1 The SCREW of the HANGING TWIN-WHEEL is loose.</p>  <p>How to solve: Refasten the SCREW of HANGING TWIN-WHEEL.</p>	<p>Cause 2 HANGING TWIN-WHEEL is broken.</p>  <p>How to solve: Replace a new one HANGING TWIN-WHEEL.</p>	<p>Cause 3 HANGING TWIN-WHEEL is dirty.</p>  <p>How to solve: Clean the HANGING TWIN-WHEEL.</p>
<p>Cause 4 ALUMINUM PROFILE is dirty.</p>  <p>How to solve: Clean the ALUMINUM PROFILE.</p>		


Our company has the following series of automatic door, please contact with our distributors/representations.

Round type door



Installation: Please in accordance with the instruction of Round Type Door.


Curved type door



Installation: Please in accordance with the instruction of Curved Type Door.


Our company has the following series of automatic door, please contact with our distributors/representations.

SINGLE-WINGED








Installation: Please in accordance with the instruction of Sliding Door.

BI-PARTING








Installation: Please in accordance with the instruction of Sliding Door.

Door-Leaf isn't smooth in operating.

<p>Cause 1 HANGING TWIN-WHEEL is not at vertical position.</p>  <p>How to solve: Readjust the HANGING TWIN-WHEEL.</p>	<p>Cause 2 1. Door touches Ground Rail. 2. Ground Rail is dirty.</p>  <p>How to solve: 1. Readjust the distance between Door and Ground Rail. 2. Clean up the Ground Rail.</p>	<p>Cause 3 ALUMINUM PROFILE is not vertical.</p>  <p>How to solve: Readjust the vertical position of the ALUMINUM PROFILE.</p>
<p>Cause 4 ALUMINUM PROFILE is not at vertical position.</p>  <p>How to solve: Readjust the level position of the ALUMINUM PROFILE.</p>	<p>Cause 5 SCREW of ALUMINUM PROFILE.</p>  <p>Reverse MOTOR</p> <p>ALUMINUM PROFILE</p> <p>SCREW (for fix ALUMINUM PROFILE)</p> <p>How to solve: Unload the MOTOR, readjust the POSITION of SCREW.</p>	

Door can't be opened or closed.

<p>Cause 1 Above the Door-Leaf touched with the crossbeam.</p>  <p>Crossbeam</p> <p>How to solve: Adjustment the interval between the Door-Leaf height and Crossbeam.</p>	<p>Cause 2 The Door-Leaf touched with the Ground Guide Rail.</p>  <p>How to solve: Adjus the Door-Leaf height.</p>	<p>Cause 3 Door-Leaf derails the ALUMINUM PROFILE.</p>  <p>How to solve: Put the Door-Leaf into the ALUMINUM PROFILE again.</p>
<p>Cause 4 Door-leaf does not vertical.</p>  <p>How to solve: Adjust the Ground Guide Rail/Wheel position.</p>	<p>Cause 5 SENSOR is broken or disconnects to the MICRO-CONTROLLER.</p>  <p>How to solve: 1.If SENSOR is broken please change a new one. 2.Check SENSOR whether it connects to the MICRO-CONTROLLER.</p>	

1.COMPONENTS SPECIFICATION.....	P1
2.TECHNICAL SPECIFICATION.....	P2
3.SECTIONAL DRAWING.....	P3
4.INSTALLATION DRAWING.....	P4
5.INSTALL PROCEDURE.....	P5
6.INSTALL THE BELT ROLLER.....	P6
7.THE POSITION OF THE HANGING TWIN-WHEEL.....	P7
8.INSTALL THE RACK BELT OF 2-WINGED.....	P8
9.INSTALL THE RACK BELT OF 4-WINGED.....	P9
10.ADJUST THE DOOR-LEAF.....	P10
11.CONNECTION.....	P11
12.CONNECTION(OPTIONAL DEVICE).....	P12
13.TEST AND ADJUST.....	P14
14.ADJUSTMENT.....	P15
15.BROKEN CHECKING.....	P17
16.TROUBLESHOOTING.....	P18
17.TROUBLESHOOTING(ILLUSTRATED).....	P19



MICRO-CONTROLLER



BRUSHLESS DC MOTOR



RACK BELT



DOOR SCREWS (8 pcs 2-winged)
(16 pcs 4-winged)



SCREWS of ACTIVE /PASSIVE BRACE (3 pcs 2-winged)
(7 pcs 4-winged)



BLOCK SCREWS (8 pcs 2-winged)
(16 pcs 4-winged)



STOPER (2 pcs 2-winged)
(4 pcs 4-winged)



WASHER (8 pcs 2-winged)
(16 pcs 4-winged)



HANGING BRACE MEDIUM (2pcs 2-winged)
(FOR DOOR LEAF UNDER 4CM) (4 pcs 4-winged)



ACTIVE BRACE



PASSIVE BRACE



BELT BRACE



BELT FIXER-2 PCS



BELT ROLLER



Inside door-leaf
HANGING TWIN-WHEEL(right side)



Inside door-leaf
HANGING TWIN-WHEEL(left side)
Only for 4-winged



Outside door-leaf
HANGING TWIN-WHEEL (1set 2-winged)
(2set 4-winged)



SENSORS
(OPTIONAL DEVICE)




WIRE CLAMP-5 PCS




Hanging Brace (4pcs 2-winged)
(8pcs 4-winged)

PROBLEMS	REASONABLE	CHECK	HOW TO SOLVE
DOOR CAN'T BE MOVED.	1.No power.	Broken circuit.	Check the broken circuit position.
		The Power Switch is not opened.	Open the POWER SWITCH.
	2.The door is locked.	Door is locked and no movement action.	Open the DOOR LOCK.
3.The sensor is broken.	Signal light is WORKING.	Check the MICRO-CONTROLLER.	
	Signal light is OUT OF WORKING.	Check the CIRCUIT OF SENSOR or change a new one SENSOR.	
SPEED	1.Speed is too slow.	Check the Speed at KNOB of MICRO-CONTROLLER.	Adjust the Speed of Open/Closed Door.
	2.Door runs into the obstructor, then cause the Door moving slow.	Installation problem or dirty.	Reinstall or clean the ALUMINUM PROFILE.
	3.Door is difficult to move.	Turn off the power.Use hand to move the Door, besides, check the Ground Guide Rail whether it is dirty.	Clean the Ground Guide Rail.
		Check the HANGING TWIN-WHEEL whether it is broken.	Change a new one.
		Check the Door Bolt in the door bottom whether it is loosen.	Fix the Door Bolt.
		Check whether the Ground Wheel is broken.	Change a new Ground wheel.
DOOR CAN'T FULL OPEN.	In the Half-Open way.	Check the Knob/Switch.	Turn on to Full Open.
DOOR CAN'T CLOSE.	1.In the Full-Open way.	The SENSOR keeps working.	Check wiring or change a new SENSOR.
	2.The Door opens suddenly while it is moving to close.	The SENSOR probably is installed with something wrong.	Adjust the SENSOR or change a new one.



TYPE	TH-W2	
MODEL	Telescopic 2-winged	Telescopic 4-winged
DOOR WEIGHT	130kg X2(door)	90kg X4(door)
DOOR WIDTH	DW=500mm~3000mm	DW=500mm~3000mm
INSTALL WAY	Surface install	Surface install
MOTOR	DC24V 75W BRUSHLESS DC MOTOR	
CONTROL	STANDARD MICRO-CONTROLLER	
POWER CONSUMPTION	75W	
VOLTAGE	AC100V~240V	
ENVIRONMENTAL TEMPERATURE	-20℃~+50℃	
VOLUME	60decibel(max.)	
STARTING SPEED	650mm(second)	600mm(second)
STARTING TIMES	0~20 sec. (regulable)	
TRANSMISSION IMPORTANT CONDITION	RACK BELT S8M	
OPENING DOOR RANGE	FULL/HALF-OPEN (regulable)	
PFC POWER EFFICIENCY	0.95(in AC100V Full load)	
TRACTION FORCE	3 kg	



E The closing speed of the door

Adjust the **CLOSED SPEED**
Higher number, faster speed.

CAUTION: please adjust the number one by one from low to high.



F The slowing range of closing door

Adjust the **SLOW RANGE** of CLOSED DOOR
Higher number, more range about the slow range at open door position.

CAUTION: please adjust the number one by one from high to low.



G The slowing speed of the door

Adjust the **SLOW SPEED**
Higher number, faster speed.

CAUTION: please adjust the number one by one from low to high.



H Opening hold time

Adjust the **HOLD OPEN TIME**
Higher number, the hold time is longer.

NUMBER	0	1	2	3	4	5	6	7	8	9
SECOND	0	1	2	3	4	5	6	10	15	20



A Full/Half opening

Adjust the RANGE of the HALF OPEN DISTANCE.
Higher number, wider range.



B Brake power

The Door-Leaf is slight, the BRAKE POWER is less.
Please choose 0~2 if the Door-Leaf is under 50kg.
Please adjust number from number 5 if the Door-Leaf is over 80kg.



C The opening speed of the door


Adjust the OPEN SPEED
Higher number, faster speed.
CAUTION: please adjust the number one by one from low to high.



D The slowing range of opening door

Adjust the SLOW RANGE of OPENING DOOR
Higher number, more range about the slow range at open door position.
CAUTION: please adjust the number one by one from high to low.

Door thickness less than 40 mm Door thickness over 40 mm



1 Prepare Should correct the height and the leveling of the ALUMINUM PROFILE



2 Cut and install the ALUMINUM PROFILE



3 Install the SENSORS



4 MOTOR



5 MICRO-CONTROLLER

6 Install the BELT ROLLER



7 Hang and adjust the Door-Leaf



8 Install and adjust the BELT



9 Power connect




10 Test and adjust

Before turn on the power, make sure the Door-Leaf can be smoothly moved, and the electric link is correct at first.

1.SYSTEM PROGRAM REMEMBER

After turn on the power, the MICRO-CONTROLLER will remember the distance and the range.

2.ADJUST



Red LED-Power is connected.

Green LED-Input the open door signal.

L/ R switch-The direction of the door opening: right/left(R/L).


Fingered Switch- Pin 1 - Directional Function

Operation $\left\{ \begin{array}{l} \text{OFF: Normal mode.} \\ \text{ON: push once, open the door. Push again, close the door.} \end{array} \right.$


Fingered Switch- Pin 2- Reverse Switch: in order to control opening and closing direction of the Door-Leaf after power resumes.

Operation $\left\{ \begin{array}{l} \text{OFF: Normal mode, after power resumes, the Door-Leaf opens the door first.} \\ \text{ON: suitable for Security System, after power resumes, the Door-Leaf closes the door first.} \end{array} \right.$

TH-100 Wiring diagram (Optional Device)




- (A) The FUNCTION of the ELECTRIC LOCK will work when ① and ② are short circuit, then ③ and ④ will output DC13V for ELECTRIC LOCK after the door closes. ⑤ and ⑥ will not output DC13V if ⑦ and ⑧ are not short circuit.
- (B) The SIGNAL of the SAFETY BEAM is controlled by ⑨ and ⑩. When door is opening and running, ⑨ and ⑩ keep to accept the signal, then the SAFETY BEAM will be working. ⑪ and ⑫ will not work when the door is closed, then the SAFETY BEAM will lose efficacy when the door is closed.
- (C) Please according with the connection way if it was installed "Selector", "Remote", "Sensors of inside and outside" at the same time; The entrance guard is under controlled by "Selector", furthermore, please extra contact ⑬ and ⑭ for the open door signal of "without control". .eg. Extra install a BUTTON or CARD READER....
- (D) The signal of Side Screen Safety Sensor is controlled by ⑮ and ⑯. Side Screen Safety Sensors are placed at the rear end of the door to prevent collisions during the opening movement of the moving leaves. When the signal activates, the moving leaves will become slowly, till the door opens fully, then close normally.




TENSION of BELT can be adjusted by the ADJUSTABLE SCREW of BELT, after that, must tighten the FIXED SCREW of BELT.

TELESCOPIC 2-WINGED
SLIDING DOORS



TELESCOPIC 4-WINGED
SLIDING DOORS



Output connect


9P terminal

Black	Red	Orange
Yellow	Green	Blue
Purple	Gray	

4P terminal

Black	Red
Orange	Orange

MICRO-CONTROLLER




Connect to Terminal Block

- Red DC13V⁺
- Black GND ⁻
- Blue ———— Output NC signal
- Green ————
- Orange ———— ELECTRIC LOCK enable
- Yellow ————
- Gray ———— Full/Half opening signal
- Purple ————

- Red DC24V⁺
- Black GND ⁻
- Orange ———— Power of SENSOR
- Orange ———— The signal of SENSOR


PS : 5P terminal is required using with Combined Terminal Block.

The illustration of the ELECTRIC LOCK contact



PS : After the orange and the yellow lines are short circuit, the blue and the green lines would output NC signal.

To join the POWER SWITCH



The ILLUSTRATED of CONTROLLER and MOTOR.

Power supply (input)
Either AC100V~240V

To join the MOTOR


POWER SWITCH



Warning

Please confirm WHETHER the SENSOR VOLTAGE is the same as the power supply. If different between them, need to add the TRANSFORMER, otherwise the SENSOR would be burned.

TELESCOPIC 2-WINGED
SLIDING DOORS





Belt fixer fixes below the upper belt.

Belt fixer fixes below the low belt.

After belt fixer fixes up the low belt, fix in profile.

TELESCOPIC 4-WINGED
SLIDING DOORS



- A** When Door-Leaf height and interval need to adjust, loose (3) & (4) at first, then adjust (1).
- B** Need to fasten (3) & (4) after adjust **A** .
- C** Install above-mentioned (2) after make sure the DOOR OPEN POSITION.